## **PHILIPS**

## Quick Start Guide


PET739














• Charging of the DVD player only possible in the power-off mode.






























© 2009 Koninklijke Philips Electronics N.V. All rights reserved.



PET739 QSG EN V1.2





